

XL Juicer



**Instruction Manual
L'EQUIP Juicer Model 215**

Important Safeguards

When using your L'EQUIP Model 215, please keep the following safeguards and precautions in mind:

- Before you begin operating your juicer, please read all of these instructions.
- Avoid body contact with any of the juicer's moving parts.
- Do not put your fingers or other foreign objects into any of the juicer's openings while it is in operation. If any food pieces should become lodged in the feed tube, use the food pusher or another piece of fruit or vegetable to push it down. If it's not possible to correct the problem with this method, turn the motor off and disassemble juicer to remove the remaining food.
- To protect against the risk of electrical shock, DO NOT put the motor base in water or any other liquid.
- DO NOT operate any appliance with a damaged cord or plug, or after the appliance malfunctions or is dropped or damaged in any manner. Return the appliance to the nearest authorized service facility for a thorough examination, and any needed repairs, or electrical or mechanical adjustments.
- The use of attachments not sold by or recommended by the manufacturer may cause fire, electrical shock or other injury.
- Unplug from electrical outlet when not in use, before assembling or disassembling and before cleaning.
- DO NOT unplug from electrical outlet by pulling on the cord. To unplug, grasp the plug, not the cord, and pull.
- Turn off all controls before unplugging from or plugging into an electrical outlet.
- Always make sure the juicer cover is securely fastened in place before the motor is turned on. DO NOT unfasten while the juicer is in operation.
- Be sure to turn switch to off position after every use of the juicer. Make sure the motor stops completely before disassembling.
- Close supervision is necessary when any appliance is used by or in the presence of children.
- DO NOT let cord hang over edge of table or counter.
- DO NOT use outdoors
- Save these instructions

L'EQUIP, Life in Healthy Balance

You're now the proud owner of L'EQUIP Model 215. This juicer was designed with your convenience in mind- you will appreciate its ease of operation as you enjoy the **delicious** and **healthy** juices it gives you.




Introduction

The L'EQUIP Model 215 comes almost completely assembled in the box. To complete the assembly before its initial use, spring loose each side clamp by pulling out the bottom of each clamp, lift the cover, lightly press the blade/basket down into place and rotate with your fingers to make certain it is locked down and can move freely. Replace the cover, bring clamps up and notch over the cover, pressing in and down at the same time. You should hear a click, and clamps should be secure against the side of the juicer with no free play left. We suggest taking your juicer apart and washing the removable parts in warm soapy water before its first use. This will eliminate any traces of dust or residue from manufacturing or shipping. Washing these parts with any liquid detergent is fine.

Assembly

Always make sure the juicer is unplugged before beginning assembly.



1. Place the juicebowl on top of the motor base. Guide ring located on the underside of the juice bowl should rest in accompanying guide slot on top of the motor base.

2. Set the blade/basket on the hub in the center of the juice bowl, and press down until it feels snug.

3. Gently rotate the blade/basket to ensure that it turns freely. If initially it failed to seat, this should slip it into place. Double check by pressing down and spinning it again.

4. Place the clear cover over the juice bowl with the large pulp ejection opening toward the back of the juicer.

5. Place the tops of the clamps on the respective slots on the cover, leaving the clamp hinges resting out. Press the bottom of the clamps in, until they snap snugly into place.


6. Place the pulp basket under the pulp spout behind the juicer.

Cleaning Your Juicer

- All parts are washable in warm soapy water except the motor base.
- Use any liquid dishwashing detergent. DO NOT use any products containing ammonia, bleach or scouring powders. These products will dull, scratch or mar the plastic surface.
- Disassemble according to instructions on page 6.
- To clean cover and juice bowl, use a soft sponge or dish mop. To clean blade/basket, invert basket assembly under faucet so that water passes through the outside to the inside. Use a scotch pad or soft brush to clean pulp from basket.
- Sponge off the motor base and legs underneath in case any juice has spilled under the juicer.
- After prolonged use, the cover, blade/basket assembly, bowl and plunger may start to show mineral deposits. To remove deposits submerge in a solution containing ½ cup of automatic dish washing detergent and a sink full of water overnight. Then rinse thoroughly.
- For your convenience, all parts, excluding motor base are also dishwasher safe, on top rack only.
- Any other servicing should be performed by authorized service personnel only.

Disassembly

Always make sure the juicer is unplugged before beginning disassembly.



1. Remove the clamps by bracing each thumb on the top or middle of each clamp...


2. ...and use one or two fingers to pull out the bottom of each clamp. Let the clamps hang from the sides by the lower hinges.

3. Lift up the clear cover from the juicer.

4. Lift off the juicebowl and blade/basket as one piece. These two pieces will then easily come apart for cleaning.

Juicing Tips

- For the best results while juicing fruits and vegetables, press slowly and firmly on food plunger at a steady rate.
- Trimming stalks and stems off of produce is recommended. It will make a less bitter juice.
- When juicing a combination of fruits or vegetables, feed the machine slowly between combinations of fruits or vegetables.
- Always try to select fresh, firm produce.
- Remember to always wash produce free of dirt and insecticides.
- Juice from fruits and vegetables should be consumed immediately after juicing, before oxidation occurs.
- For the best results for your health, we recommend to drink two or three glasses of fresh juice daily.



For More Information:

Once you've read this manual and tried your L'EQUIP Model 215, you may still have questions. If you need additional assistance, contact us at:

**KITCHEN RESOURCE
180 WEST 500 NORTH
NORTH SALT LAKE, UT 84054
1.800.692.6724**